

## **EcoDim-Triac Series**

1 Gang 2 Way 60-400W Zero Cross Rotary Dimmer



## **Features:**

- Leading edge phase control
- For use with resistive and inductive loads
- Integrated over-temperature protection fuse
- Module case ultrasonically sealed to reduce dimmer buzzing
- Smooth dimming operation from 0-100%
- May be fitted to most dimmer plates
- Complies with the latest Electrical Safety
  Standard for dimmer switches EN60669-2-1:2000
- EMC Compliance EN550155

M			н.
IWI	( n	r=1	ш

	2002	
Specifications		
Input Voltage Type	AC	
Input Voltage (Max)	240V	
Input Voltage (Min)	220V	
Size	62.2 x 26 x 46.2 mm	

### **Important User Information**

- De rate dimmer by 70% for LED Loads.
- Do not mix lamp types and wattages on the same lighting circuit.
- Before switching off the lamps turn the dimmer switch to maximum, this will ensure that the lamps are at the correct voltage when next switched on.
- Always wait for lamps to reach full brightness before setting the dimming level.
- Module only Faceplate not included.

#### **Important Installation Information**

#### Always switch off mains supply before installation or maintenance works.

- Fit the dimmer module to the required plate.
- Remove the existing switch taking note of the wiring terminations. If there are two or more wires in one terminal connect them into the same terminal on the ECODIM-TRIAC.
- When stripping the cables for termination ensure that bare conductors do not project from the terminals.
- When the wiring is connected the dimmer switch can be adjusted for minimum dimming level.
  - 1. Turn the dimmer switch clockwise
  - 2. Using a small terminal screwdriver turn the potentiometer (side of the dimmer module) anticlockwise.
  - 3. Switch on the mains supply.
  - 4. When the lamps are at full brightness slowly turn the dimmer switch fully anti-clockwise.
  - 5. Turn the potentiometer clockwise until the desired minimum light level is reached.
  - 6. If it is turned too far the lamps may extinguish, repeat steps 1-6.
- Install the dimmer plate into the wall box ensuring that the wiring is not trapped. Tighten the plate fixing screws.
- A slight buzzing noise may be heard from the dimmer switch in operation, this is perfectly normal.





# **EcoDim-Triac Series**


1 Gang 2 Way 60-400W Zero Cross Rotary Dimmer

#### **Connecting Diagram**

This dimmer module is suitable for 1 or 2 way lighting circuits and has 3 screw terminal connections L1, L2 and C (common). NOTE: When using 2-way switching lamps could be switched off while dimmed.

#### 1-Way Switching

- Each lighting circuit is controlled by one switch.
- Connect the incoming Live to the terminal marked C.
- Connect either L1 or L2 to the live feed to the lighting circuit.
- For 1 way switching either the L1 or L2 terminal connection is not used.



#### 2-Way Switching

- 2-Way lighting circuits have two switches controlling the same lights from two different locations.
- This arrangement is commonly used at the top and bottom of staircases or at the entry and exit doors to a room.
- Only one standard plate switch may be replaced with a dimmer switch for 2-way switching applications or the lights will flicker on and off.
- See Figure for a typical 2-way circuit.
- Remove one of the existing switches taking note of the wiring of the switch and the terminal markings.
- The wires connected to the COMMON terminal of the plate switch should be connected to the C terminal of the dimmer switch.
- The wires connected to the other two terminals of the plate switch should be connected either way round to terminals L1 & L2 of the dimmer switch.

